

# Controller programming with CoDeSys for an automated timber sorting system

---

Nils Breitholtz



UPPSALA  
UNIVERSITET

**Teknisk- naturvetenskaplig fakultet  
UTH-enheten**

Besöksadress:  
Ångströmlaboratoriet  
Lägerhyddsvägen 1  
Hus 4, Plan 0

Postadress:  
Box 536  
751 21 Uppsala

Telefon:  
018 – 471 30 03

Telefax:  
018 – 471 30 00

Hemsida:  
<http://www.teknat.uu.se/student>

## Abstract

### **Controller programming with CoDeSys for an automated timber sorting system**

*Nils Breitholtz*

This report describes the development of weight measurement application and transducer positioning for the A Sort prototype that has been developed for automatic grading and sorting of timber. The prototype consists of a transportation system with hydraulic and electrical motors, a measurement system with laser scanners and acoustic measurement equipment and a control program for the automated process with CoDeSys. The objective was to integrate these parts in an automatic system process, controlling a prototype designed for acoustic measurement of logs. The devices were installed and configured to communicate via an existing fieldbus line using CANopen as communication protocol. A control program was made for each task and implemented in the control process for the automatic measurement of logs. Two load cells were installed beneath a moving tilt and the measurement equipment was tested and calibrated using three different logs with known weight. The testing showed that in order to get higher accuracy the construction needs to be modified. Photo cells were installed on the measurement frames and a program was made in order to make the acoustic measurement of the logs work properly.


Handledare: Christer Karlsson  
Ämnesgranskare: Ping Wu  
Examinator: Tomas Nyberg  
ISSN: 1401-5757, UPTec F10 040

<b>1</b>	<b>BACKGROUND .....</b>	<b>4</b>
<b>2</b>	<b>PRINCIPLE OF AUTOMATIC CONTROL .....</b>	<b>5</b>
2.1	FIELDBUS SYSTEMS .....	5
2.2	CAN – CONTROLLER AREA NETWORK [1] .....	6
2.2.1	<i>The Physical layer.....</i>	6
2.2.2	<i>The Data Link layer.....</i>	7
2.2.3	<i>Bus arbitration and error management.....</i>	8
2.3	THE APPLICATION LAYER – CANOPEN [4].....	8
2.4	PLC AND SOFTPLC .....	10
2.5	CoDeSys – A PROGRAMMING ENVIRONMENT FOR PLC AND SOFTPLC .....	10
<b>3</b>	<b>THE PROTOTYPE.....</b>	<b>12</b>
3.1	FEATURES .....	12
3.2	THE CONTROL PROGRAM .....	13
3.3	LOG TRANSPORTATION.....	14
3.3.1	<i>The conveyer in table – Conv_in(PRG).....</i>	14
3.3.2	<i>The step feeder – Step_feeder(PRG) .....</i>	14
3.3.3	<i>The roller conveyer – Roller_conv(PRG).....</i>	15
3.3.4	<i>The feeder wheel – Feeder_wheel(PRG).....</i>	15
3.3.5	<i>The tilt – Tilt(PRG) .....</i>	15
3.3.6	<i>The conveyer out table – Conv_out(PRG).....</i>	15
3.4	THE HYDRAULIC SYSTEM .....	15
<b>4</b>	<b>WEIGHT MEASUREMENT .....</b>	<b>17</b>
4.1	LOAD CELLS[8] .....	17
4.2	COMMUNICATION WITH THE NODE.....	19
4.3	WEIGHT MEASUREMENT PROGRAM.....	23
4.4	RESULTS .....	25
4.4.1	<i>Empty cradle .....</i>	25
4.4.2	<i>Result test 1: Log weight 116 kg .....</i>	25
4.4.3	<i>Result test 2: Log weight 181 kg .....</i>	26
4.4.4	<i>Result test 3: Log weight 225 kg .....</i>	26
<b>5</b>	<b>MEASUREMENT FRAME POSITIONING.....</b>	<b>29</b>
5.1	IMPLEMENTATION.....	30
5.2	THE PROGRAM .....	32
<b>6</b>	<b>CONCLUSIONS AND SUGGESTIONS FOR FUTURE WORK .....</b>	<b>36</b>
<b>7</b>	<b>REFERENCES .....</b>	<b>37</b>

# 1 Background

Use of automatic control has grown rapidly during the last century and is now a mandatory part of our industry. As with the introduction of programmable logic controllers (PLCs) and microcomputers in the late 1960s control engineering has become more related to electrical and computer engineering. The implementation of fieldbus systems and industrial networking in general has made it possible to coordinate a multiple of control applications, creating a control system. These control applications could be, for example, motion control, mathematical calculation processes, digital signal processing or pneumatic- and hydraulic control, all ran or supervised by a single or a network of computers. Today's market offers a number of possible solutions regarding communication protocols, centralized or distributed I/Os, program developing environments and system configuration in general, all depending on different user demands. In order to determine which system products are best suited for an application, a large number of aspects have to be taken into account, making the selection process very demanding.

A Sort AB is currently developing a prototype for automatic sorting of timber (Fig. 1.1). The idea is, by using acoustic measurement, to pre-sort timber before it goes into sawing mill. The prototype is designed to transport a log through a system of different measuring devices to gather information needed to determine the physical properties of the log. In order to do that the sorting process needs to be controlled and coordinated in the aspects of the measurement devices and the transportation of logs. The main purpose of this thesis is to determine the mass of logs along with the development of a method for the positioning of measurement equipment for the prototype. A main tool for this thesis project is CoDeSys (**C**ontroller **D**evelopment **S**ystem) which is a comprehensive software tool for industrial automation technology [3]. The fieldbus in use is controller area network (CAN) [6] along with CANopen, a CAN-based application protocol [4].



*Fig. 1.1 The A Sort prototype*

## 2 Principle of automatic control

### 2.1 Fieldbus Systems

Fieldbus systems are a fundamental concept in automatic control. A definition for *fieldbus* given in the IEC 61158<sup>1</sup> fieldbus standard is “A fieldbus is a digital, serial multidrop, data bus for communication with industrial control and instrumentation devices such as – but not limited to – transducers, actuators and local controllers.”[1] This could be considered as a bit diffuse. But the fieldbus itself is only an integrative part of a control system, a way to gather and share information over a network. Instead of using separate cables to each device from the controlling unit, the bus line links all of the system parts together with a single cable. To make this work, all the parts of the system have to communicate according to a common protocol.




Fig. 2.1 CAN according to the ISO/OSI model

Fieldbus protocols are, like all modern communication systems, modelled according to the ISO/OSI<sup>2</sup> model with a stack containing seven layers, but the protocols only have three of them in practical use in process control applications: the application layer on the top and the data link and physical layer at the bottom (Fig. 2.1). To determine a standard, these layers need to interact without losing compatibility with control applications in different areas. As well as the different requirements from the various automation domains, the winnings in the aspect of market shares influenced the developers to a number of different solutions. As a result of this, the concept of fieldbus has become the centre of a standardisation conflict that has lasted over almost a decade and has left us a large variety of fieldbuses (e.g. Profibus, PROFINet, ControlNet, Interbus and WorldFIP) and adapted devices to choose from when designing a control system.

The property of information exchange differs regarding what process needs to be automated. There are three different basic communication paradigms declared for industrial networks:

- Client-server model
- Producer-consumer model
- Publisher-subscriber model

These have different communication properties regarding connections (connection oriented or connectionless) and relations (peer to peer, broadcast or multicast; and mono-master or multi-

---

<sup>1</sup> IEC – International Electrotechnical Commission.

<sup>2</sup> ISO – International Organization for Standardization; OSI – Open Systems Interconnection.

master, etc.). They are often combined in a number of ways in fieldbus systems, e.g. CAN (Control Area Network) is mainly a combination of the producer-consumer and the publisher-subscriber model. Yet, it implements some of the features recognised as the client-server model which makes, in some sense, this labelling a bit pointless in this case.

## 2.2 CAN – Controller Area Network [1 ]

CAN has its origin in a serial bus system originally developed for the automation industry back in the 1980s by Bosch. It was intended to be used in passenger cars because the bus systems that were available on the market at that time were not suitable for their application. This system *Automotive Serial Controller Area Network* proved its qualities in the area of error management and congestions, enough to survive and evolve into today's CAN. From this, two different solutions of CAN controllers surfaced: BasicCAN by Philips and FullCAN by Intel. BasicCAN is a simpler version that only involves send and receive buffers where message handling is run by the CPU. The CPU has to request or acknowledge the data via interrupts, which will in the end burden the CPU. FullCAN involves a set of buffers called mailboxes that handle information according to contents, where no involvement of the CPU is needed. These two architectures have been more or less united, when modern CAN chips are structured as a combination of both.

As told above fieldbuses in general can be modelled with three layers according to the ISO/OSI standard model. CAN, on the other hand, only consists of two: the data link layer and the physical layer. The application layer is covered by some of the CAN-based application protocols such as CANopen, DeviceNet, etc. The physical layer handles the function of the mechanical and electrical aspects, i.e., the connections, wiring and transmission media as well as the synchronization and bit timing. The data link layer is split into two sub layers: MAC (medium access control) and LLC (logical link control). The MAC sub layer controls the activity and access to the bus to avoid collisions between different transmitting devices whereas the LLC handles the bus arbitration on a higher level as well as frame encoding, decoding and error checking.

### 2.2.1 The Physical layer

The most common physical medium for data transfer is a two-wire bus, using a differential signal transmission with common return. The two wires, CAN-high and CAN-low, are preferably shielded twisted pair, which increases the immunity to electromagnetic interference [1]. There are two standards defined, ISO 11519 (CAN low speed) and ISO 11898 (CAN high speed). CAN low speed has an upper bit rate limit of 125 kbit/s and CAN high speed is within the range of 10 kbit/s to 1 Mbit/s. For CAN high speed (used in the A Sort prototype), each end of the bus line has to be terminated with a resistance of approximately 120  $\Omega$ [5] to suppress signal reflection (Fig. 2.2).




Fig. 2.2 Description of the CAN high speed bus line and the signal levels The bus assumes two different states or levels and

since the outputs of the nodes connected to the bus are based on the principle of an *open-collector* it will work as a wired-AND. A wired-AND works like a Boolean AND, in this case meaning that any node transmitting lower level output will result in a low bus level. The two bus levels are referred to as *dominant* and *recessive* where the logical value of the dominant level is 0 and the logical value of the recessive level is 1. CAN uses non-return to zero bit encoding which basically means that there is no “neutral state” in between the bits. This means that level on the bus will remain unchanged when transmitting a consecutive series of values. Therefore, an additional synchronisation is needed to avoid errors, or “bit-slips”. By using a digital phase-locked loop each node can extract the necessary bit-timing information from the flanks in the bit stream[1]. And to ensure a decent level of synchronisation CAN adds a sufficient number of flanks in the bit stream, by so-called bit-stuffing. Five bits of the same logical value will be followed by an extra bit of the opposite value, and thereby adding an extra flank in a consecutive bit stream. These extra bits are removed, or de-stuffed, by the receiver.

## 2.2.2 The Data Link layer

CAN is a multi master network where a data frame is addressed with an *identifier* rather than an actual node address. Here, CAN specification uses two types of frame formats, the *standard* (CAN 2.0A) with an 11-bit *identifier* field (

**Fig. 2.3**) and the *extended* (CAN 2.0B) format with an extra 18-bit *identifier* field giving a total of half a billion different objects in the same network. Modern systems are in most cases capable of recognizing and adjusting to both formats but the standard CAN 2.0A is most common and sufficient for almost any application.




Fig. 2.3 The frame format in standard CAN

When the network is idle and no frames are being sent, the level on the bus is recessive. Every data frame starts with a dominant SOF (*start-of-frame*) bit which indicates that a message is about to be sent and synchronises the receiving nodes (

**Fig. 2.3**). After the SOF, the identifier follows, and then the RTR bit (*remote transmission request*) that defines if data is being sent or requested. If the RTR bit is dominant, the data is being sent and not requested which gives data messages a higher priority than requests. The SOF, identifier and RTR represent the arbitration field. If extended identifier is being used, this field will also contain the IDE (*identifier extension*) bit and the SSR bit (*substitute remote request*). This field is followed by the control field with two reserved bits ( $r_1$ ,  $r_2$ ) and the 4 bit long DLC (*data length code*) which gives the length of the data field, in bytes. The length of the data field can be at the most 8 bytes long and is followed by an error checking 15-bit CRC (*cyclic redundancy check*) and an acknowledgment field, which consist of two bits. These two bits are recessive where the first one is overwritten with a dominant bit by each node on receiving end that has detected and received the message correctly. The frame ends with the EOF (*end-of-frame*) and IMS (*intermission*). EOF is 7 recessive bits, letting everyone know that the transmission was error free. IMS consists of three recessive bits that separates the frame from the one next to be sent.

### 2.2.3 Bus arbitration and error management

CAN uses CSMA/CD + AMP, *Carrier Sense Multiple Access/Collision Detection with Arbitration on Message Priority*, which is a protocol for several transmitting units shearing the same medium. The CD+AMP addition means when collision occurs, a predefined protocol determines a “winner” who is allowed to continue transmitting. This is an advantageous feature compared to other protocols when collisions results in transmission failure and the message has to be re-transmitted after a specified time. The bus arbitration in CAN is basically determining whether a recessive or a dominant bit is being sent. If two nodes are sending a message at the same time, they keep communicating until one of them “looses” by sending a high bit that is “pulled down” by the dominant bus level. This way a frame is always exchanged in case of collision, which makes CAN quite insensitive to high bus loads. The CAN specification provides five different ways to detect errors. Apart from the acknowledgment field and the CRC mentioned above, it is possible to check the frame format itself by comparing the value of the expected recessive bits at receiving ends. *Bit monitoring* is also provided meaning that each node compares the value of the bus with the one that is being written. Whenever an error is detected by any node in the network 7 dominant bits are transmitted as an error messages. The *Bit stuffing technique*, mentioned earlier, will avoid any non-error messages containing 7 straight dominant bits being mistaken for an error message since a recessive bit will be stuffed in between.

## 2.3 The Application layer – CANopen [4]

CANopen is one of the higher-layer protocols available for the CAN standard that only defines low layers like data link and physical layers. Each of the protocols defines an application protocol to cover the information exchanges between different devices. In CANopen the information exchange is provided by *communication objects* (COBs). There are four different COBs, covering different areas:

- Processes data objects (PDOs) for real-time data exchange.
- Service data object (SDOs) for parameter setting and diagnostics.
- Emergency objects (EMCY) for error messaging.
- Synchronization objects (SYNC) for synchronization and coordination.

Even if CAN in general is defined as what resembles a multi master network where every device has equal rights, CANopen has a default master-slave approach. This is to make network configuration easier where you only have one network master and up to 127 slave devices, each with a unique node ID. The 11-bit identifier field (Fig. 2.4) in CANopen starts with a 4-bit function code. This function code defines the type of the message, i.e., COB, and sets the priority. As mentioned, a lower value results in a higher priority. The function code is followed by a 7-bit node ID, a unique id-number for every device part of the CANopen network.




Fig. 2.4 Description of the identifier field



All relevant information about a device is described as different objects. These objects relate to different areas, covering all the need-to-know information and the behaviour of the device. These objects are stored in the *object dictionary* (OD) of the device and are addressed through 16-bit index. The information could be represented by a single value, or stored in an array where an additional sub-index is needed. The data exchange involving the OD, is handled through the *Service Data Objects* (SDO's). The SDO's are sent with low priority and are a mandatory part of the configuration phase during boot-up. A larger amount of data can also be exchanged with SDO's by sending the data in blocks or in segments. The communication using SDO's is in the scope of a client/server relationship.

Real-time data, demanding high priority, is sent using *Processes Data Objects* (PDO's). PDO's are referred to as TPDO's or RPDO's depending on whether they are transmitting or receiving data. A device that is transmitting data is named PDO producer and a receiving device PDO consumer. There are two different modes for transmitting PDO's:

- Synchronous
- Asynchronous

Synchronous transmissions are fixed in time within a communication cycle. A communication cycle is defined by producing a recurring SYNC message, an event that triggers the devices to transmit the PDO's. The SYNC message is given very high priority and is generated periodically by a synchronisation application. The synchronous PDO's are then sent within the next synchronization window, defined by a time after the SYNC message, and can be set to be transmitted cyclic or acyclic. Acyclic means that the PDO's are sent within that window, but not periodically since it's triggered by another event rather than the SYNC message.

The transmission can be triggered by an event or after an elapsed time during which no device-specific event has occurred. Asynchronous PDO's are sent without any relation to the SYNC message. They can also be remotely requested by another device, a PDO consumer, by setting the RTR bit in the data field.




Fig. 2.5 PDO transmission

## 2.4 PLC and SoftPLC

PLC stands for Programmable Logic Controller and has been replacing sequential relay circuits and timers for machine control in our industries since the late 1960's. It was first developed by Bedford Associates who presented a "computerized" solution that was requested by a major US car manufacturer. The goal was to eliminate the cost from replacing hardware in the relay based machine control system. Since the first PLC, Modicon 084 (MODular DIgital CONTroller), was present in 1968 [7]. PLC has become an essential part in today's automation and is designed to endure the strains of that environment.

Basically a PLC consists of a number of inputs and outputs, a memory and a program. Depending on the states of inputs, certain conditions are fulfilled and executed by the program and the outputs are set to certain values. This is all done once each cycle. The PLC can be compact or modular where the latter are expandable in the sense of number of I/O's.

As we all know, the market for personal computers, PC's, has been, and still is, expanding in an exploding rate. The high-end technical thirst from us end-users as well as the pushing requirement demands from software developers has led to an extremely high development pace from the hardware manufactures. Even if the PLC manufactures have proven themselves worthy, the PLC's are a bit lag behind in the sense of performance in comparison to PC's. Hence the solution soft PLC has emerged in which the capability of a PC is used together with remote I/O's and the PC software simply mimics the PLC. A remote I/O gathers and networks information from a number of sources onto one communication link, i.e., the fieldbus.

There are many opinions on whether to use "the more reliable" PLC or a "more powerful" PC-based soft PLC, but we are not going to discuss them here. However, it can be noted that the manufacture of the first PLC now uses PC-based control in there production. Soft PLC is also used for the prototype.

## 2.5 CoDeSys – A programming environment for PLC and SoftPLC

CoDeSys (**C**ontroller **D**evelopment **S**ystem) is a development environment that generates machine code from a program to a desired target system, e.g., PLC or SoftPLC. CoDeSys supports six different languages for developing a program:

1. Instruction List (IL). Reminds of assembler and was more often used back in the days.
2. Structured Text (ST). A high-level language much like C and Pascal.
3. Function Block Diagram (FDB). A graphic tool for making the schematics of the logical in- and outputs.
4. Ladder Diagram (LD). A graphic language reminding of relay schematics. A language developed in cases where the user has an electrician background.
5. Sequential Function Chart (SFC). A graphic tool optimised to structure the different elements of a program.
6. Continuous Function Chart Editor (CFC). A more open version of FDB which allows feedback signals for example.

The first five are defined by the IEC 61131-3 standard. The language used throughout this project was consequently ST. Regardless of what computer language you prefer the program application is structured as different POU's (*Program Organisation Units*). The main program is by default named PLC\_PRG and this is where the process begins. From here the other

programs and functions are called. In addition to this, there is an opportunity to use the *Task Manager*. A *Task* is the processing of an IEC program which can be configured manually. The *Task* needs to be given a name, priority and triggering condition for starting the *Task*. The starting condition can be set to run cyclic at a time interval or in freewheeling mode, which means that it starts over as soon as possible after finishing a *Task*. The task can also be triggered by an internal or external event.

In order to configure the CANOpen network CoDeSys needs all the information about the different nodes which is stored in their *object dictionary (OD)*. To define the different objects in the OD the manufactures of the devices provides EDS-files (Electrical Data Sheets). In the early versions of CoDeSys, the bus data was handled externally, where a software module was needed to collect and interpreter the data. This is now implemented into CoDeSys with library functions that automatically generates databases matching the configuration of the network. The EDS-files included in the sub-directory PLCCONFIG in the library will be available for implementation and editing when creating the CANOpen network. The library functions handle all access including start up and error monitoring of the network and can be called from the application.


At start up, the master will reset all nodes either one by one or by using a broadcast message with Node ID 0. Every slave will now be configured by initially calling the first object of the “communication area profile” in the OD, which refers to the device type. The slave has to respond within a time wait in order for the next SDO to be sent. The slave can be set as optional and in that case, no more SDO’s will be sent. If the object does not match the configuration in use, it will still be configured, though falsely. During start up, the master changes status as boot up process proceeds. The current state is given by the variable **nStatus** in the library function **CanOpenMaster**, e.g., **nStatus** = 5 means that everything is up and running. The slaves are then started, either manually or by checking the “Automatic start-up” box in the configuration. Start up can also be done one by one or by using a broadcast message. Just like the master, the slaves also change their states during start up where the variable, **nStatus**, is in the library function **CanOpenNodes**. The variables in the library function are accessible through “CanOpen Implicit Variables” in the project, as global variables.

CoDeSys features an integrated development tool for visualization and the runtime system needed for the execution, CoDeSys HMI (human-machine interface). This built-in HMI was used in this project and contains a visualisation editor with the basic features useful for simpler applications. The advantage of using a built-in HMI is obvious in the development phase where code and variable changes are updated globally.

## 3 The Prototype

### 3.1 Features

The prototype was developed and manufactured during 2007, tailor made in order to fulfil A-Sort's demands. Earlier measurements had been carried out by hand with promising results, but to convince the conservative forest industry that these measuring methods could fit in a future production line, a full scale model was needed. The need was to transport the log through and between different measuring devices all in an automatic way.



*Fig. 3.1 Schematics drawing of the prototype*

In the aspect of a control system it can be divided into two different categories, transportation and measurement, which together have to interact with each other.

The transportation of logs is conducted in the following manner (Fig. 3.1)

1. Conveyor in: A conveyor table, using a transportation chain to move the logs into the prototype sideways. This is driven by a 3.1 kW geared induction motor which is controlled directly by a contactor switch.
2. Step feeder: A hydraulic “staircase” that moves the logs, one by one, up to the roller conveyor.
3. Roller conveyor: A bed of wheels that move the log through a laser scanner and into the tilt. The transportation wheels are linked with a chain and driven by an induction motor. The motor is controlled by a variable frequency drive without feedback.
4. Feeder wheel. A rotating wheel driven by an induction motor that is controlled by a variable frequency drive without feedback. The wheel is mounted on a hydraulic arm that moves down from above and presses on to the log, and then drives it forward to the tilt.
5. Tilt: A hydraulic cradle that tilts the log to the first measurement position to have the weight measured, then to the second measurement position to get the acoustic measurements, and finally out onto the conveyor out table. The tilt is pushed back and forward by two hydraulic arms. An encoder is mounted on the tilt giving the angle for positioning. The tilt is suspended upon to load cells used for weight measurements.
6. Conveyor out. A conveyor table, using a transporting chain to move the log out from the prototype sideways. This is driven by a 3.1 kW geared induction motor which is controlled directly by a contactor switch.

The measurement of a log consists of three different parts:

1. Measurement of volume: The log runs through a laser scanner which determines the log's length and diameter. The laser scanning system contains of a laser detector and a laser server that communicates with CoDeSys via OPC<sup>3</sup>.
2. Measurement of mass: The tilt is suspended by two load cells and weight is measured during standstill.
3. Measurement of acoustic properties: When the tilt reaches its second measurement position the acoustic measurement devices are "pushed" against both ends of the log. These devices are mounted on two measurement frames. These are manoeuvrable in two directions and adjustable in one additional, depending on the length and diameter of the log. Each frame is driven by three different servomotors which are all controlled by servo drives with feedback. Data from the laser server are used to position these frames.

### 3.2 The control program

As said before a control program in CoDeSys contains different POU's. Besides it also consists of *visualizations* and *resources*. *Visualisation* is a tool for building a HMI for where the variables and the process are monitored. *Resources* contains the necessary configuration tools, including declaration for global variables, library manager, PLC configuration etc. The POU's are structured in following categories:




Fig. 3.2 The POU branches in CoDeSys

0. Global function blocks. Contains different functions, Pos\_cntrl and Pulse\_timer. Pos\_cntrl is a PID regulator used to control the servo motors. The function is called from category 4, Log meas equipm pos. Pulse\_timer is a function that switches between logical 1 and 0 at a given interval, creating pulses for warning lights and alarm sounds.
1. Main. The program referred to main in C is by default called PLC\_PRG and is located in this category. From here all the other programs and function are called every cycle. In this case Main also contains two other programs, Feeder\_wheel\_filter and Spd\_meas. These programs are not executed every cycle by PLC\_PRG, instead they each have a Task triggering them at a specified time interval. Feeder\_wheel\_filter is a filter for the torque values of the feeder wheel given by the servo drives. The intention is to supervise the applied torque in order to assist the photocell that detects the log when it reaches its end position in the tilt.

<sup>3</sup> OPC = OLE for Process Control; OLE = Object Linking and Embedding

- If the applied torque is too high under a certain time the feeder wheel will stop. Spd\_meas measures and translates the velocity into mm/s.
2. **Global control.** Global\_control supervises the safety relays and circuits and controls the ON/OFF function of the system. Hyd\_motor manages the star-delta start up sequence for the hydraulic motor, which is discussed more in the following chapter.
  3. **Log Transp.** The transportation of the log is divided between six different components in the system: Conv\_in, Conv\_out, Feeder\_wheel, Roller\_conv, Step\_feeder and Tilt. The features of these programs will be discussed more thorough later, in the “Log transportation” chapter.
  4. **Log meas equipm pos.** Since there are two measuring frames, this category contains Meas\_equipm\_pos\_fwd and Meas\_equipm\_pos\_rear that each consists of similar program parts. This will be discussed more thoroughly later.
  5. **Measuring.** Contains programs essential for classifying the log. Depending on the result each log is painted with a colour which is done by the program named Marking. Weight contains the sequence for the weight measurement process. Measuring and Hammer\_seq provides the necessary data and logical output to determine the quality of the log.
  9. **HMI.** Contains programs that visualize different events and status of the process in the HMI. It also manages a history function where data is saved and old data can be accessed.

### **3.3 Log Transportation**

The following is a short description of the transportation system to give a brief understanding of the structure of the code and to describe how the different parts of the program interacts with each other.

#### **3.3.1 The conveyer in table – Conv\_in(PRG)**

The measurement procedure starts with the conveyer in table that moves the logs sideways into the prototype using a transportation chain. This is driven by a 3.1 kW geared induction motor which is controlled by a contactor switch. A photo cell is placed at the end of the table, indicating when a log is in position for delivery. Depending on the status of the Step-feeder the logs will be delivered one by one or placed on hold at stand-by. If the photo cell does not detect anything the transportation has limit time of 2 minutes in case of an empty table. In this case it will try again every 5 minutes.

#### **3.3.2 The step feeder – Step\_feeder(PRG)**

The step feeder is, as mentioned, a hydraulic staircase that pushes the logs into the prototype one log at the time. At the end of the staircase is a roller conveyer to which the step feeder feeds the logs one at a time. The step feeder is equipped with two photo cells, one at each end, that indicates the status of receive and delivery. In the HMI there is an option available of choosing between a continuous flow or just a specific number of logs in the step feeder at once. This feature was added as a tool to simplify the development by reducing the pace. This option was kept as a redundant part in case of later adjustments. To maintain sufficiency, the step feeder always tries to contain the maximum number of logs before making a delivery. Delivery will only occur when the roller conveyer signals ready to receive.

### **3.3.3 The roller conveyer – *Roller\_conv(PRG)***

The roller conveyer is a bed of wheels that forwards the log through a laser scanner system and upon the tilt. The wheels are connected by a chain that is driven by an induction motor and controlled by a variable frequency drive without feedback. Upon the roller conveyer a photocell is mounted to register any log on the conveyer. Every time the photocell registers a log a status bit is set true that indicates that it is not ready to receive any logs at the time. This bit will remain true until the conveyer has run forward for 3 seconds while the signal from the photocell is false. The roller conveyer will run forward if the tilt is empty and in position and if the feeder wheel is out of the way. The conveyer will stop when the log is detected at the end of the tilt.

### **3.3.4 The feeder wheel – *Feeder\_wheel(PRG)***

When the log has passed through the laser scanning system the feeder wheel will lower and transport the log further upon the tilt. The feeder wheel will be notified by the roller conveyer that the log is on its way. It also has a photocell mounted underneath it that is triggered when the log passes. Further on the tilt there are two photocells that help determining the logs whereabouts. The feeder wheel starts as soon as the log reaches it but will not lower until it is confirmed that it has passed. This is to avoid collision where an early descending will block the path of the log. While descending, it will adjust its speed according to the speed of the roller conveyer. When the log reaches the end of the tilt the wheel will be stopped and the hydraulic arm will rise. Here a status bit will be set true that the wheel is up and by this telling the tilt and the measuring frames to continue.

### **3.3.5 The tilt – *Tilt(PRG)***

When the log reaches the end of the tilt it will be detected by at least one of the two photocells mounted there. The photocells are connected in parallel to widen the area of detection. As soon as the feeder wheel is up the tilt will start forward until it reaches its most upright position. There it will make a short stop to measure the weight and then continue until it reaches the measuring position. It will then remain there at standstill until the measuring of the log is done and the frames are out of the way. The tilt will then continue forward until the log rolls out onto the conveyer out table.

### **3.3.6 The conveyer out table – *Conv\_out(PRG)***

The conveyer out table works just like the conveyer in table where a transportation chain moves the logs away from the prototype. A photocell is placed at the end where the logs arrive from the tilt. As soon as it detects a log the conveyer moves forward until the photocell is free.

## **3.4 The hydraulic system**

All of the hydraulic parts of the system are connected to a hydraulic pump powered by a 30 kW, three-phase, induction motor. The pressure is distributed with electrical valves that are controlled by the program. Each valve is connected to a remote digital I/O (bus node) in the CANopen network and is controlled by setting a value to the corresponding Boolean variable in control program. Since the hydraulic motor is of considerable size (30 kW), it is necessary to reduce the increased power consumption due to start-up. The starting torque, that is formed when the rotor is still in stand still, increases the current with approximately a factor 6-8 compared to the rated current, which in this case is 55 A. The simplest way of doing this is to use a star-delta switch(Fig. 3.3). By reducing the voltage over each coil from 380 V to 220 V the current will be reduce by a factor  $1/\sqrt{3}$ . The principle is to start the engine in star

connection where the voltage over each coil is the same as between each phase and the common return, i.e. 220 V. Then switch to delta connection when the engine has reached the desired rpm. Now each coil will be connected between two phases where the differential voltage is 380 V.




Fig. 3.3 Schematics of star to delta connection

This is done by using three contactors, one applying 380 V directly to the input terminals U1, V1 and W1 and two other contactors connected to the other end of each coil, U2, V2 and W2. Depending on the status of contactors on the backside, the windings are either short circuit (star connection) or connected between to another phase (delta connection). All three contactors are connected to a remote I/O and thereby controlled by the program.




Fig. 3.4 To the left and in the middle: The electrical drawings of the system. To the right: a description of the start up sequence

However, to use a star-delta connection is not recommended when starting motors connected to fans or pumps, since the applied torque from these increases with the rpm. This results in a current and torque pike when switching from star to delta connection. If the counter torque excides the torque during start up, the rotor may stall. This is a theory of what happened when trying to start up the engine when using an insufficient transformer, not delivering enough power. Due the power dip during start up the applied voltage and thereby the torque was insufficient to start the motor. This was solved by installing an additional valve to reduce the pressure in the hydraulic pump during start up. The valve is controlled manually and is to be opened after the motor is in full speed in order for the system to work properly.



## 4 Weight measurement

### 4.1 Load cells[8]

To define the quality of the log the weight is needed in order to determine the density. Two load cells are mounted underneath the tilt absorbing the force along “vertical axis”. The load cells are supported with two additional telescope axles, only absorbing any radial force acting on the tilt. This free floating suspension on the load cells makes the tilt a scale.




Fig. 4.1 To the left: a load cell mounted beneath the tilt. To the right: an example of a strain gauge

The load cell that is used to measure the weight of the log is of strain-gauge type which is probably the most common type of load cell on the market today. Basically, the load cell converts a force into an electrical output using a strain-gauge which is a thin conductive wire that experiences an elastic deformation due to an acting force. The wire is applied on the measuring object in a pattern that will maximize the physical change in one direction. The wire will either become longer and thinner or shorter and thicker as a force is acting on the object. This will cause its electrical resistance,  $R$ , to change as the cross section area,  $A$ , and the length,  $L$ , of the wire is altered. The resistance of a conductive material is given by:

$$R = \rho \cdot \frac{L}{A} \quad \text{where } \rho \text{ is the resistivity of the material, which in this case is assumed}$$

unchanged. The change in resistance caused by the physical deformation is defined as

$$\Delta = \frac{dR}{R}$$

and is added to the resistance measured in the unstressed mode:

$$R = R_0 \cdot (1 + \Delta)$$



Fig. 4.2 A strain-gauge deformed due to an applied force. To the left: unstressed mode. In the middle: the cross section area of the wire is decreased. To the right: the cross section area of the wire is increased

Change in resistance usually measured with a Wheatstone-bridge which gives a differential output voltage due to the unbalanced resistance:

$$U_D = U_V \cdot \left( \frac{R_X}{R_3 + R_X} - \frac{R_2}{R_1 + R_2} \right)$$

As the resistance is altered due to the strain gauge being stretched or compressed, the reference voltage will be:




Fig. 4.3 A wheatstone-bridge

$$U_D = U_V \cdot \left( \frac{R_X + \Delta R_X}{R_3 + R_X + \Delta R_X} - \frac{R_2}{R_1 + R_2} \right)$$

Since the strain-gauge is made of a different material than the one that it is applied on, they will react differently to a change in temperature. This will create a physical deformation and a change in resistance that is unrelated to any force applied to the object. A way to avoid this is to use dummy strain-gauges instead as reference resistors, since they will react in the same way. The symmetrical s-shape makes it possible to use four strain-gauges, working in pairs, and not just as dummy gauges. In this way, two strain-gauges are stretched when the other two is being compressed.




Fig. 4.4 Two strain gauges applied on both sides

And since the change in resistance due to a change in temperature is equal to all strain-gauges, its contribution will be zero.

If the strain gauges are balanced i.e. as having the same resistance in unstressed mode, we have  $R_1 = R_2 = R_3 = R_4 = R$  and  $\Delta_1$  and  $\Delta_2$  represents the relative change in resistance from strain and contraction.

$$\begin{aligned}
U_D &= U_v \cdot \left( \frac{R + \Delta_1 R}{R + \Delta_2 R + R + \Delta_1 R} - \frac{R + \Delta_2 R}{R + \Delta_1 R + R + \Delta_2 R} \right) = \\
&= U_v \cdot \left( \frac{R}{2R + \Delta_1 R + \Delta_2 R} + \frac{\Delta_1 R}{2R + \Delta_1 R + \Delta_2 R} - \frac{R}{2R + \Delta_1 R + \Delta_2 R} - \frac{\Delta_2 R}{2R + \Delta_1 R + \Delta_2 R} \right) = \\
&= U_v \cdot \left( \frac{\Delta_1 R - \Delta_2 R}{2R + \Delta_1 R + \Delta_2 R} \right)
\end{aligned}$$

If we assume that the change in resistance is equal in both cases, i.e.  $\Delta_1 R = -\Delta_2 R$ , we get:

$$U_D = U_v \cdot \frac{\Delta R}{R}$$

The model used in this project is a Vetek TS, a tension-compression s-beam load cell with a maximum force of 10 kN. It has a nominal sensitivity of 2 mV/V which means that if the applied differential voltage is 10 volt the output signal will be in the range of -20 to 20mV. The sign is whether the force acting on the load cell is from tension or compression.

## 4.2 Communication with the node

To interpret the electrical output and to convert it to a binary signal, an analogue input terminal, KL3351, was used. KL3351 (Figure 4.6) has eight front panel connections: four input connections, two output for supply voltage and two connections for shielding. The output signal from the terminal has a 16 bit resolution of 500nV/digit for the measured change in voltage and 500μV/digit for the reference voltage.




Fig. 4.5 The KL3351 terminal

We use an external power supply terminal for the applied differential voltage of 10 V instead of the built in 5 V to obtain a better resolution.

To communicate with the terminal e.g. to read the values in our program the KL3351 is connected to a CanOpen Bus Coupler, BK5120. The communication within the node runs through the internal K-bus, along with the power supply for the terminal.

The bus coupler is connected to the CANopen network over which the data is exchanged. As mentioned before the real time data is exchanged via PDO's which are configured in CoDeSys, in the *PLC Configuration*. A bus node is added to the network by inserting as an element. This can be done after adding the EDS file of the device in the PLCCOFNIG in the library. In order to create a CANopen network you need to create a NMT master named CAN-Master.




Fig. 4.6 Electrical drawing of the connection

The CAN-Master will have Node-ID 1, and will also be the configuration master. It will determine the baud rate along with the Communication Cycle Period and the Communication window length. This are set according to the number of PDO's that are set to be sent cyclic and synchronous on the network. When the master is configured all slaves needs to be inserted as an element and configured. They require a unique Node-ID between the numbers of 2 and 127 and depending on the device the different COB's has to be added.




Fig. 4.7 PLC configuration from CoDeSys with a short description of the nodes

The input terminal for weight measuring is placed at node 13. The node consists of the following devices.

- BK5120 - Bus coupler
- 4 x KL1012 – 2-channel digital input
- 2 x KL2424 – 4-channel digital output
- KL5001 – Special input, SSI (Synchronous Serial Interface) encoder interface terminal
- KL3202 – Analogue input, resistance thermometer
- KL9510– 10 V power supply unit
- 2 x KL3351 – Analogue input, resistor bridge terminal

Given by the EDS-file, the I/O types to choose among are

- 1-8 bytes special I/O
- Analogue I/O
- Digital I/O
- Write/Read State 8 I/O lines

By definition, maximum data length of each PDO is 8 bytes. It is also recommended by the vendors to separate digital and analogue channels in different PDO's and not to mix them. As mentioned earlier output data is mapped as receive and input data as send, i.e. the mapping is seen from the node's perspective. Since the output from the node only consists of eight digital channels there's only one receiving PDO containing eight output bits. When mapping digital channels you can either map them as digital I/O's or as Write/Read State 8 I/O lines.

The first send PDO consists of eight input digital channels which in this case are mapped as Read State 8 I/O lines. The PDO exchange with the SSI encoder interface is done with Special Inputs and is thereby mapped in the next PDO. In order to get the node to communicate properly the special inputs from the SSI encoder needed to be mapped in 6 bytes, by this 2 extra special inputs was added. This was investigated and determined empirically after numerous tries that ended in communication failure, setting the state machine of the slave to nStatus=98. Apart from that fact, the extra 2 special inputs were needed to get the addressing

right for the analogue inputs. For that reason, the extra bytes worked as dummy mapping. The third PDO starts with the analogue input from the resistance thermometer. Since it is a two channel terminal the next input from the resistor bridge needs to be mapped as “input 3” instead of “input 2”. This could have been solved by adding an extra analogue input as dummy mapping. Both analogue inputs from the last terminal are placed in the fourth PDO since it is not recommended to split data from a single terminal in different PDO’s.




Fig. 4.8 PLC configuration from CoDeSys with a special attention to node 13

One problem that occurred was that before these testing began, the load cells experienced a bit of a miss happening. Due to some wrongly installed hydraulic pipes the tilt was forced into the “wrong” direction, resulting in huge force on the load cell, by far exceeding the maximum limit of 7.5 kN. The load cells experienced a plastic deformation, not detectable by the human eye. This gave the output signal an offset of approximately 150 mV. Since the maximum input signal to the terminal was limited to -16 to 16 mV the output signal from the terminal described an error message instead of the measured weight. After realizing this, the load cells were replaced (by the load cells described earlier) and the PDO’s could be mapped correctly.

In order to calculate the weight, we need the output signal  $U_d$  as well as the reference signal  $U_{ref}$  to get a proper value, since the output voltage changes with the applied voltage. Therefore two analogue inputs are created in the send PDO’s folder for each KL3351 terminal. Each analogue input word is named `NODE_13_KL3351_x`, since the node address

is 13 in the fieldbus configuration. The variables used in the program are declared under Global variables\CANOpen\_Node\_13\_I/O and then tagged to these input words in the action inputs in the PLC[PRG] like follows:

```
Bridge_rear_UD:=NODE_13_KL3351_1;
Bridge_rear_Uref:=NODE_13_KL3351_2;
Bridge_fwd_UD:=NODE_13_KL3351_3;
Bridge_fwd_Uref:=NODE_13_KL3351_4;
```

As said before the nominal sensitivity of the load cell is 2 mV/V. This means that the Scale\_factor\_to\_kg is given by the maximum load divided by the nominal sensitivity which in this case is:

$$Scale\_factor = \frac{\text{maximum load}}{\text{nominal sensitivity}} = \frac{1000 [kg]}{2 [mV/V]} = 500 [kg \cdot V / mV]$$

The applied weight for each load cell:

$$Applied\ weight = \frac{U_D [mV]}{U_{ref} [V]} \cdot 500 [kg \cdot V / mV]$$

The formula used to calculate the weight of the log is then given by:

$$Log\_mass = Mech\_scale\_factor \cdot Scale\_factor\_to\_kg \cdot \left( \frac{Bridge\_rear\_U_D}{Bridge\_rear\_U_{ref}} + \frac{Bridge\_fwd\_U_D}{Bridge\_fwd\_U_{ref}} \right) - Mass\_of\_tilt$$

### 4.3 Weight measurement program

In order to keep the structure of application in a uniform manner, the POU Weight is created in directory Measurements along with other data regarding physical characteristics of the log. The program is of state-case structure and is triggered by the position of the tilt. The tilt needs to be in its most upright position to get the total weight upon the load cells, otherwise the force will be divided into several components. The tilt also has to be at standstill to attain readings without disturbance from forces caused by any movement and vibrations. It's also favourable to wait a few seconds during standstill for the tilt to stabilize while reading the values during a period of time to get a mean value. The values are first filtered to avoid any signal disturbances by sorting them by size and then selecting and discarding the smallest and the greatest values.

```
(*Incoming or "Raw"-weight *)
Weight:=Mech_scale_factor*Scale_factor_to_kg*(Bridge_rear_UD/Bridge_fwd_UD + Bridge_rear_Uref/Bridge_fwd_Uref)-Mass_of_tilt;

IF Weight>=Filter_weight THEN                                (*When incoming value is higher than current value "in use"*)
  FOR F_index:=1 TO Array_size-1 DO                          (*Loops, one step at the time through the array*)
    IF Log_mass>Log_mass_arr[F_index+1] THEN                (*Compares incoming value with the values in the array, moving up*)
      Log_mass_arr[F_index]:=Log_mass_arr[F_index+1];      (*If larger -move the value in the array down*)
    ELSE
      EXIT;
    END_IF
  END_FOR
END_FOR
```

```

ELSE
    FOR F_index:=Array_size TO 2 BY -1 DO
        IF Log_mass<Log_mass_arr[F_index-1] THEN
            Log_mass_arr[F_index]:=Log_mass_arr[F_index-1];
        ELSE
            EXIT;
        END_IF
    END_FOR
END_IF
Log_mass_arr[F_index]:=Weight;

Tmp_value:=0;
FOR F_index:=3 TO Array_size-2 BY +1 DO
    Tmp_value:=Tmp_value+Log_mass_arr[F_index];
END_FOR
Filter_weight:=Tmp_value/(Array_size-4);

```

(\*When incoming value is smaller then current value "in use"\*)  
(\*Loops backwards through the array, one step at the time\*)  
(\*Compares incoming value with the values in the array, moving down\*)  
(\*If smaller -move the value in the array up\*)  
(\*Writes the value at current position in the array\*)  
(\*Resets the temporary value, used for the calculation of a mean value\*)  
(\*Steps through the middle part of the array, by that sorting out the \*)  
(\*largest and the smallest values and then adding them\*)  
(\*Saving the mean value of the added values\*)

To make Weight(PRG) work as intended, the program Tilt has to work according to certain specifications. This means that when the tilt receives the log it will move forward until it reaches its most upright position. Since the positioning with hydraulic engines is rather inaccurate, this condition is fulfilled when the tilt is within a suited position window. When this condition is fulfilled, the tilt waits until the weight measurement is done and then it continues.

```

Filter;

CASE State OF

0:  Weight_measuring_done:= FALSE;
    IF Tilt.Log_in_weight_pos THEN
        State:= 10;
    END_IF

10: Log_in_pos_delay(IN:=TRUE, PT:=T#4.5S);
    IF Log_in_pos_delay.Q THEN
        Read_weight_delay(IN:=TRUE, PT:=T#0.1S);
        Weight_angle:=Tilt_angle;
        IF Read_weight_delay.Q AND Index < 10 THEN
            Tmp_weight:= Tmp_weight + Filter_weight;
            Index:= Index + 1;
            Read_weight_delay(IN:=FALSE);
        ELSIF Read_weight_delay.Q AND Index = 10 THEN
            Log_mass:= Tmp_weight/10;
            Weight_measuring_done:= TRUE;
            Log_in_pos_delay(IN:=FALSE);
            Read_weight_delay(IN:=FALSE);
            State:=20;
        END_IF
    END_IF

20: IF Measuring.Log_done OR Tilt.Log_in_pos THEN
    State:= 0;
END_IF

END_CASE

```

(\*Activating Filter\*)  
(\*Resets the measuring done bit \*)  
(\*Starts the weight process when the tilt is in upright position\*)  
(\*Wait 4,5 sec. before reading\*)  
(\*Wait 4,5 sec. before reading\*)  
(\*Reads every 0,1 sec.\*)  
(\*Saves the angle for reference check\*)  
(\*Reads one value every 0,1 sec. until ten value are summarized\*)  
(\*and stored in Tmp\_weight\*)  
(\*Tmp\_weight is divided by 10 to obtain a mean value over one sec.\*)  
(\*Sets bit true\*)  
(\*Timer reset\*)  
(\*Timer reset\*)  
(\*Resets the measuring process\*)

The weight measurement was tested with three logs of known weight. Their reference weight was measured with a scale with an approximated error of 0,01 %, but to be realistic, the reference weight was rounded to a kilo. This is due the fact of the difficulty of weighing a 5 meter long, 150 kg heavy log without a tractor ore a crane. By way of introduction, the mass of the tilt had to be established. A mean value was calculated from 15 different measurements and inserted in the program as an offset.



## 4.4 Results

### 4.4.1 Empty cradle

Result	Quantity
449	1
450	1
451	3
452	4
453	5
454	0
455	1

Standard deviation = 1.464

Variance = 2.143

Mean value = 452




Table 4-1 Determining the weight of the cradle

Then each log was weighed 15 times in real-alike circumstances, which in this case meant running the log back and forth through the system to ensure different positions in the cradle. From this a mean value was calculated as well as a scale factor for each weight. These three different scale factors were compared and from them a mean value was calculated and later used in the program. Since the value of the horizontal axis do not in fact represent the measured weight in kg, but only the reading in digits from the terminal, the unit has been left out on purpose.

### 4.4.2 Result test 1: Log weight 116 kg

Result	Quantity
571	1
572	5
573	3
574	1
575	1
576	3
578	1

Standard deviation = 2.059

Variance = 4.239

Mean value = 574

Meaan value, log only = 122

Conversion factor = 0,951




Table 4-2 Test 1, log weight 116 kg

#### 4.4.3 Result test 2: Log weight 181 kg

Result	Quantity
633	2
636	2
637	1
638	2
640	1
641	1
642	1
644	3
647	1
648	1

Standard deviation = 4.785  
Variance = 22,896  
Mean value = 640  
Mean value, log only = 188  
Conversion factor = 0.963




Table 4-3 Test 2, log weight 181kg

#### 4.4.4 Result test 3: Log weight 225 kg

Result	Quantity
681	1
682	1
683	1
684	5
685	1
686	2
687	3
693	1

Standard deviation = 2.83  
Variance = 8.01  
Mean value = 685  
Mean value, log only = 233  
Scale factor = 0.966




Table 4-4 Test 3, log weight 225 kg

When first testing the equipment a disturbingly large difference in result was measured. It was obvious that the scale was not sufficient enough and the test was aborted. After determining that the signal from the load cell was interpreted correctly, the tilt was examined. After a closer look it was easy to realize the construction was a bit skew, and when moving back and forth the frictional forces and tensions within the structure differed between the

measurements. Due to a deadline there was no time to demount and reconstruct the tilt so the solution was to balance the tilt in its position.

The fact that the load cells are placed directly under a moving object makes the measurement angle very delicate. If the tilt was perfectly stable and moving without any frictional forces at all the measurement angle could simply been compensated for. Since this was not our case, there was a need to be sure that load was directly above the load cell and that the angle was the same every time at the point of measurement. To be sure of this an extra condition was added in the program, ensuring a correct angle when the tilt stops for weight measurement. If the tilt misses the spot a re-attempt will be made ensuring that the weight measurement will be made within a defined position window. After a couple of test runs it was clear that there was a problem with the accuracy. The aimed position was often missed with as much as 2 degrees and sometimes 5 retries was needed before ending up within the position window. This, of course, could not be accepted and after reviewing the whole system it became clear that the tilt was not the only part lacking accuracy. Since the servo motors also had trouble positioning themselves and they, along with the tilt, have a more then enough resolution from the encoders the problem was assumed to be deriving from the communication with the devices. Especially since the problem seemed to be escalating when running the entire system, compared to test driving one part at the time. After going through the parameters for the CAN Master in the PLC configuration it was noticed that the communication cycle period and the synch. window was both set to 1 ms. A too short communication cycle would lead to bus overload and thereby a communication delay. And if the synch. window is as short as the communication cycle any PDO defined as asynchronous may not be sent if the cycle window is “full” and there is no room “outside” the synch. window. This happened in an early stage of the prototype when all the PDO’s had to be defined as synchronous in order to work.

The baud rate is set to 125 kbit/s and this along with the amount of data determines the length of the cycle period. The total amount of data transmitted over the bus is described as follows:

Node no.	No. of bytes (out)	No. of bytes (in)	No. PDO's (out)	No. PDO's (in)
1.		4	2	1
2.		3	1	1
3.		1	21	1
4.		0	1	1
5.		0	1	1
6.		0	1	1
7.		6	6	1
8.		6	8	1
9.		6	8	1
10.		6	8	1
11.		6	8	1
12.		6	8	1
13.		6	8	1
14.		6	8	1
Σ		56	89	14

Table 4-5 List of all the PDO transmission along with the size of the data

IN: 16 PDO + 89 bytes → 704 bits + 712 bits = 1416 bits

OUT: 11 PDO, 56 bytes → 484 bits + 448 bits = 932 bits

This gives us a total of 2348 bits. With a baud rate of 125 Kbit/s this means that the cycle period needs to be at least

$$\frac{2348 \text{ bit}}{125 \text{ Kbit/s}} = 18,74 \text{ ms}$$

A reasonable bus load is said to be 80 % so therefore the cycle time should be at least


$$18,74 \cdot 1,25 \approx 25 \text{ ms}$$

This gives us a buffer in case of a worst case scenario regarding the bit stuffing.

Note: After changing the cycle time to 25 ms the accuracy was greatly improved.

## 5 Measurement frame positioning


The acoustic measurement instruments are installed in two measurement frames. Each frame has three servomotors with feedback position encoders. The first motor moves the frame in the horizontal direction, the second in the vertical while the third adjusts the positioning radius of the transducers (i.e., two impact hammers and two accelerometers on one frame, and four acoustic receivers on the other). The servomotors are intended to make good contact between the transducers and both ends of the log, where the ends are preferable in the centre of the frames. The radius of the transducer positions should also be as close to the log boundary as possible. The length and the diameter obtained from the laser scanner system are used for positioning. As long as the size has been measured and the log has been confirmed being ready for transport on the tilt, the frames start to make their vertical and radial positions. To avoid collision when tilt moves the log forward, the frames are kept apart until the tilt has reached the measuring position.



*Fig. 5.1 The measurement frames*

Each frame is equipped with a photocell placed approximately 15 cm in front of the frame and pointing in the vertical direction (Fig. 5.1). This is to alert the frame it is about to make contact with the log. The frame first reaching this position makes a short stop to await the other frame to make the same progress on the other side. Both ends will then make contact with the corresponding transducers simultaneously. The reason for this is that the Y-frame tilt is covered with reels on two rows and only one frame making contact will push the log sideways. Unfortunately, logs are often not shaped as perfect cylinders. Instead they come in various shapes, with the result that the approximated positions of the log ends tend to disagree with reality. The effect of this can be that some of the transducers can not gain contact with the log and the measurement will be a failure.

The program was at first designed to try again with a smaller radius to minimize the risk of the transducers being outside the boundary of the log. This resulted in a time waste apart from the risk of damaging the equipment when every attempt of measuring without full contact is hazardous.



*Fig. 5.2 The movement of the tilt in relation to the frame*

To solve this problem an additional photocell was installed, pointing to the end of the log in the horizontal direction and directing the frame to place its centre in front of the log. It is mounted in top of the frame and moves inward the centre as the radius of the transducers' positions is decreased. This adjustment in position is made just before reaching the log. The idea is to first decrease the radius and, if necessary, then move the frame until the end of the log is detected by the photocell.

## **5.1 Implementation**

Each frame is run by a program, controlling the movements of all three motors in three different directions. In order to get the equipment in place for measurement the following actions are needed from the control system

- Read the current position
- Calculate the target position
- Move the equipment to the target position

The position of each motor is given by a SSI (Synchronous Serial Interface) encoder, which consists of a number of turning discs. The encoders are absolute, which means that each angular position corresponds to the numerical value which remains unchanged when the power is turned off. However, in this project, the encoder values are used as a reference to a fixed position, given by a sensor. This position is found just when the equipment touches the sensor, and stored as the reference for calculating a new position. This point is also set as "home"- or "zero" position. Due to this, an internal counter was created in case the maximum number of encoder turns is exceeded. The encoder resolution is set to 4096 counts per revolution, which in this case is more than enough since one revolution corresponds to 3 mm.

Each servo motor is driven by a servo drive. The servo drive monitors the position of the motor from the SSI encoder and provides the current and frequency to adjust the torque and speed. Each servo drive is connected to the CAN bus from where the position of each motor is transferred back to the control program. The position given by the SSI encoder is stored in three 16 bit registers, #03.28, #03.29 and #03.30, and by defining these as TPDO this

information is accessible by the control program. Also, register #10.40 is defined as TPDO to provide the control program with all the useful information regarding the status of the servo drive.

The target position is calculated by using data (i.e., log's length and radius) provided by the laser scanning system. The length is only used as a guiding value since the photocells on the measurement frames are used to detect both ends of the log. This is in some sense also true for the radius value since the additional photocell, described earlier, was installed. The vertical position is calculated by using the fact that three distances  $r$ ,  $a$  and  $b$  (Fig. 5.3) form a right triangle. The distance from the centre of the log to the known reference point is then easily calculated by using the Pythagorean theorem,

$$b^2 = a^2 + r^2$$

And since  $a = r$ , we have

$$b = \sqrt{2r^2} = r\sqrt{2}$$




Fig. 5.3 The log in position in the tilt

When the target positions are calculated a function, *Pos\_Ctrl*, is called. This function regulates the speed until the motors are in position. This can also be done using the function embedded in the drive but due to a communication error this was not possible. The speed is sent as a 32-bit value to the servo drive via a RPDO which is defined in the servo drive as parameter #01.21. The sign of that value determines in which direction the motor will run. Each servo drive has a number of inputs that control the basic functions of the drive, e.g. start, stop, etc. These are available externally or through parameter #06.42. In this case parameter #06.42 is devoted as a RPDO, and thereby these functions are activated by the control program where each function responds to a corresponding bit in a 16-bit word.

## 5.2 The program

Each frame has a similar control process which is structured in one main program calling the other function blocks each cycle (Fig. 5.3).




Fig. 5.4 Program structure of the frames in CoDeSys

**HMI:** Handles the visualisation, i.e. sets different texts or colours indicating status when driving the motors.

**In\_Uxx:** Reads the values of inputs from the servo drives and the transducers.

**Main\_case:** This part runs the motion sequence when running the process in automatic mode. A more thorough description will follow later.

**Make\_pos\_C, Make\_pos\_X, and Make\_pos\_Y:** Calculates the actual positions using the values from encoders. C denotes the radius of the equipment, X the the distance between the frames and Y the vertical position of the frames.

**Make\_set\_pos\_C, Make\_set\_pos\_X and Make\_set\_pos\_Y:** The information from the laser scanning system regarding the length and diameter of the log is used to calculate the target positions for the frames.

**Motion\_C\_case, Motion\_X\_case and Motion\_Y\_case:** This program is only for test driving the equipment.

**Out\_C, Out\_X and Out\_Y:** The values are written to the outputs, which in this case means the values of the function bits and the speed is sent to the servo drive.

**Save\_log\_end\_pos:** As a complement to the laser scanner the length of the log is calculated using positions measured by the photo cell.

As mentioned, **Main\_case** is the measuring sequence needed in order to coordinate the measuring process with the rest of the system parts.

(\* Status bit, will be true if the frames are apart and there is enough distance for a log to pass through between them\*)  
 Log\_free:=Fwd\_meas\_equipm\_in\_rear\_pos OR (NOT Log\_near\_fwd\_meas\_euipm AND Act\_pos\_X<Photocell\_hit\_pos-50 AND Photocell\_hit\_pos>0);

(\*Status bits that defines when the frame can't be re-adjusted in these directions\*)  
 At\_min\_limit\_y:=Set\_pos\_Y=min\_dist\_y;  
 At\_min\_limit\_c:=Set\_pos\_C=min\_dist\_c;

(\* True when in the lowest position \*)  
 (\* True when the radius is at min.\*)

CASE State OF

0: In\_meas\_pos:=FALSE;

(\* Resets status bit \*)

IF Auto THEN

Auto\_Bwd:=NOT Fwd\_meas\_equipm\_in\_rear\_pos AND NOT Disable\_X;

(\* Starts by returning to home position\*)

IF Fwd\_meas\_equipm\_in\_rear\_pos OR Disable\_X THEN

Auto\_Bwd:=FALSE;



```

    Auto_Dwn:=NOT Fwd_meas_equipm_in_bottom_pos AND NOT Disable_Y;(* Returns to home position *)
    Photocell_hit_pos:=0;(* Resets position value*)
    Retry_C_pos:=1.0;(* Decreasing factor(1=unused)*)
    State:=10;
END_IF
ELSE
    Auto_Bwd:=FALSE;
END_IF

10:IF Auto THEN
    Auto_Dwn:=NOT Fwd_meas_equipm_in_bottom_pos AND NOT Disable_Y;(* Continuous towards home position *)
    IF Fwd_meas_equipm_in_bottom_pos OR Disable_Y THEN
        Auto_Dwn:=FALSE;
        Auto_Apart:=NOT Fwd_meas_equipm_apart AND NOT Disable_C;(* Returns to home position*)
        State:=20;
    END_IF
ELSE
    Auto_Dwn:=FALSE;
    IF Fwd OR Up THEN(* Returns in case of manual intervention*)
        State:=0;
    END_IF
END_IF

20:IF Auto THEN
    Auto_Apart:=NOT Fwd_meas_equipm_apart AND NOT Disable_C;(* Increases the radius towards home position*)
    IF Fwd_meas_equipm_apart OR Disable_C THEN
        Auto_Apart:=FALSE;
        State:=30;(* Continuous when in home position *)
    END_IF
ELSE
    Auto_Apart:=FALSE;
    IF Fwd OR Up OR Together THEN
        State:=0;
    END_IF
END_IF

30:IF Auto AND NOT Measuring.Log_done THEN
    IF (Feeder_wheel.Log_in_pos OR Tilt.Log_in_pos) AND Log_dia_fwd_inner_mm>0 AND Log_dia_rear_inner_mm>0 THEN
        (* Status OK from other parts.*)
        Make_set_pos_y;(* Calling the positioning function*)
        Make_set_pos_c;(* Calling the positioning function*)
        Auto_pos_Y:=TRUE;(* Starts auto positioning*)
        Auto_pos_C:=TRUE;(* Starts auto positioning*)
        State:=40;
    END_IF
END_IF

40:IF Auto THEN
    Make_set_pos_y;(* Calling the positioning function*)
    Make_set_pos_c;(* Calling the positioning function*)
    Auto_pos_Y:=TRUE;(* Starts auto positioning*)
    Auto_pos_C:=TRUE;(* Starts auto positioning*)
    IF ABS(Act_pos_Y-Set_pos_Y)<Pos_window AND ABS(Act_pos_C-Set_pos_C)<Pos_window AND Log_length_mm>0 THEN
        (* If the positions are reached*)
        Make_set_pos_x;(* Call positioning function*)
        Auto_pos_X:=NOT Log_near_fwd_meas_euipm;(* Runs forward until the log is reached*)
        State:=50;
    END_IF
ELSE
    Auto_pos_Y:=FALSE;
    Auto_pos_C:=FALSE;
    IF Man_Bwd OR NOT Tilt.Log_in_pos THEN
        State:=0;
    END_IF
END_IF
(* Condition false when log has been moving out of position by the tilt*)

50:IF Auto AND (NOT Fwd_meas_equipm_in_rear_pos OR NOT Log_near_fwd_meas_euipm) THEN
    IF Log_near_fwd_meas_euipm AND NOT Log_in_CY_pos_fwd THEN(* If the frame has reached the log but it is not visible*)
        IF NOT At_min_limit_c THEN(* If it is possible to decrease the radius*)
            Set_pos_C:=LIMIT(min_dist_c, Act_pos_C - 20, max_dist_c);(* Decreases the radius by 20 mm*)
        ELSIF At_min_limit_c THEN(* Minimum radius*)
            IF NOT AT_min_limit_y THEN(* If it is possible to lower the frame*)
                Set_pos_Y:=LIMIT(min_dist_y, Act_pos_Y - 20, max_dist_y);(* Lowers the frame by 20 mm*)
            ELSIF At_min_limit_y THEN(* If the position can not be adjusted *)
                State:= 60;(* Continuous anyway*)
            END_IF
        END_IF
    END_IF
END_IF

```

```

        END_IF
    END_IF
    ELSIF Act_pos_X>Set_pos_X-Dist_photocell_to_final_pos THEN
        Set_pos_X:=Act_pos_X+Dist_photocell_to_final_pos;
    ELSIF Log_near_fwd_meas_euipm AND Log_in_CY_pos_fwd THEN
        State:=60;
    END_IF
    Auto_pos_X:=NOT Log_near_fwd_meas_euipm;
ELSE
    Auto_pos_X:=FALSE;
    Auto_pos_Y:=FALSE;
    Auto_pos_C:=FALSE;
    IF Man_Bwd OR NOT Tilt.Log_in_pos THEN
        State:=0;
    END_IF
END_IF

60:IF Auto THEN
    IF Log_near_fwd_meas_euipm THEN
        Set_pos_X:=Act_pos_X+Dist_photocell_to_final_pos;
        Auto_pos_Y:=FALSE;
        Auto_pos_C:=FALSE;
        State:=70;
    ELSIF Act_pos_X>Set_pos_X-Dist_photocell_to_final_pos THEN
        Set_pos_X:=Act_pos_X+Dist_photocell_to_final_pos;
    END_IF
    Auto_pos_X:=NOT Log_near_fwd_meas_euipm OR (Log_near_rear_meas_euipm AND Log_in_CY_pos_rear);
    ELSE
        Auto_pos_X:=FALSE;
        Auto_pos_Y:=FALSE;
        Auto_pos_C:=FALSE;
        IF Man_Bwd OR NOT Tilt.Log_in_pos THEN
            State:=0;
        END_IF
    END_IF

70: Auto_pos_X:=Auto AND (NOT Log_near_fwd_meas_euipm OR (Log_near_rear_meas_euipm AND Log_in_CY_pos_rear));
    IF ABS(Act_pos_X-Set_pos_X)<Final_pos_window THEN
        Auto_pos_X:=FALSE;
        In_meas_pos:=TRUE;
        State:=80;
    END_IF
    IF (NOT Auto AND Man_Bwd) OR NOT Tilt.Log_in_pos THEN
        State:=0;
    END_IF

80: IF Measuring.Log_done OR (NOT Auto AND Man_Bwd) THEN
        State:=0;
    ELSIF Auto AND Measuring.Retry AND NOT At_min_limit_c AND NOT Log_near_rear_meas_euipm THEN
        In_meas_pos:=FALSE;
        Set_pos_X:=MAX(Photocell_hit_pos-100,0);
        Auto_pos_X:=TRUE;
        State:=90;
    END_IF

90:IF Auto THEN
    IF NOT Log_near_fwd_meas_euipm THEN
        Auto_pos_X:=FALSE;
        Set_pos_C:=LIMIT(min_dist_c, Act_pos_C - 20, max_dist_c);
        Auto_pos_C:=TRUE;
        IF ABS(Act_pos_C-Set_pos_C)<Final_pos_window THEN
            State:=60;
        END_IF
    END_IF
    Auto_pos_X:=TRUE;
ELSE
    Auto_pos_X:=FALSE;
    Auto_pos_C:=FALSE;
END_IF

900: ;
END_CASE

```

(\* If the frame yet has not reached the log\*)  
(\* Another 15 cm will be added\*)  
(\* The frame is in position and ready\*)  
(\* Continuous forward\*)  
(\* Stop the frame\*)  
(\* Stops if there is any manual intervention\*)  
(\* The frame is in position and ready \*)  
(\* Adds the remaining distance to the log\*)  
(\* Prevents any motion\*)  
(\* Prevents any motion\*)  
(\* If the log/frame has moved out of reach\*)  
(\* Adds an extra length to the final pos. \*)  
(\* Waits for the opposite frame to get ready\*)  
(\* Waits for the opposite frame to get ready\*)  
(\* Position is within margin of error\*)  
(\* Stops motion in X-direction\*)  
(\* Confirms that the equipment is in position\*)  
(\* Manual intervention or the log has been moved\*)  
(\* When the measurement is done\*)  
(\* Returns to start\*)  
(\* Measurement failure but the equipment position is still adjustable(otherwise the other frame is)\*)  
(\* Un-confirms measurement ready\*)  
(\* Sets new target\*)  
(\* Backing the frame\*)  
(\* When the frame is out of the way of the log\*)  
(\* Stops the frame\*)  
(\* New set position for the radius\*)  
(\* Decreases the radius\*)  
(\* Returns to state 60 for a retry\*)




Fig. 5.5 The process in form of a flow chart, though a bit simplified

## **6 Conclusions and suggestions for future work**

An automatic measuring process for determining the weight of the log has been developed. Test shows that the result is within the margin of error but further “tuning” of the construction will be needed to improve the accuracy.

A process for positioning the measurement equipment has been developed. Running the system in automatic mode showed that the logs run through the process and are measured without any inconvenience. Preferable for the next version would be to have the speed regulation directly in the servo drive instead of in the control program.

This assignment was made in an early stage of the developing of a new measurement system. Therefore a lot of problems had to be solved along the way which made this an even greater experience. Since this prototype was developed for testing new equipment and not for the industry, the demands were not as high in terms of efficiency and durance. A full scale model will have to work 10-15 times as fast and will have to be far more robust. The baud rate needs to be higher and the construction has to be designed for those demanding conditions. But a lot of parts of the system was not yet fully tested and therefore will a lot of the conditions change before developing the full scale and on-line product.

## 7 References

- [1] Richard Zurawski (2005), *Industrial communication theory*, Taylor & Francis Group, ISBN 0-8493-3077-7
- [2] 3S – Smart software solutions (2006), *User documentations: CANopen for 3S Runtime systems, ver 1.1*
- [3] 3S – Smart software solutions (2003), *User manual for PLC programming with CoDeSys, ver. 1.0*
- [4] CAN in automation e.V (2002), *CANopen – application layer and communication profile, Cia draft standard 301*
- [5] CAN in automation e.V (CiA) (2007), *CANopen - additional specifications, Part 1: Cableling and pin assignment, Cia draft recommendation 303*
- [6] Bosch, Robert (1991), *CAN specification*, ver. 2.0
- [7] [Dick Morley](http://www.barn.org/FILES/historyofplc.html) (2002), The History of the PLC, [www.barn.org/FILES/historyofplc.html](http://www.barn.org/FILES/historyofplc.html).
- [8] Lars Bengtsson (2003), *Elektriska system och mätmetoder*, Studentlitteratur, ISBN 91-44-02903-9